

Using the Pelco Web Interface System

PLEASE NOTE: WHEN YOU CONNECT, THE SYSTEM WILL ASK YOU FOR A USERNAME AND PASSWORD, THE USERNAME IS: DX8000WEB PASSWORD IS: Pelco8000 Both are Case Sensitive.

Click on the link for the webcams.

Upon opening the webpage link your browser may ask to install an “Active X” control. You must allow this to install for the system to work correctly and allow viewing of the cameras.

Once you see the **Pelco** screen you will see several monitor icons at the top of the webpage. Click on the last one on the right. It looks like two monitors with a lightning bolt. A new window will pop up with a connection list. Click “*add*”. Another window will pop up labeled “*Server Information*”. Under “*Name*”, type in the word “**server**” without the quotes. Under “*IP Address*” type in “**72.2.79.246**” without the quotes. Then click “*OK*” at the bottom of the window. Click “*OK*” on the “*Connection List*” window to close it out.

You should now see the “Server” and “Cameras” listed on the left side of the web page. Expand the “Cameras” by clicking on the + sign next to “Camera”. The camera list should then drop down labeled “1-6”. Left click with your mouse on the selected camera and “Drag and Drop” it into the Blue Pelco Screen. Do this with each additional camera you want to view.

The settings will be saved the next time you open the web page so you should only have to follow these instructions one time to view the cameras.